

DEFLECTION

Deflection is always determined at midspan.

The empirical formula for deflection is:

$$D = \frac{131 \cdot W \cdot L^4}{E(OD^4 - ID^4)}$$

Where: D = Midspan deflection (in.)

OD = Outside diameter of conduit (in.)

ID = Inside diameter of conduit (in.)



E = Modulus of elasticity of conduit (psi), which is 1,400,000 for epoxy fiberglass conduit

L = Distance between hangers (ft.)

W = Total weight of cable and conduit (lbs/ft.)

It is recommended that midspan deflection never exceeds 5/8 inches (16 mm).

Below are easy graphs for determining support distance between hangers for various diameters and wall thicknesses of conduit.



1/4" (6) Deflection

.....
1/2" (13) Deflection

—————
5/8" (16) Deflection

.....
3/4" (19) Deflection

1" (25) Deflection